

SeaTalk Technical Reference Revision 3.22

General Information

SeaTalk is a simple interface for networking [Raymarine/Autohelm](#) marine equipment so that all devices of a ship can exchange and share their data. SeaTalk is a proprietary solution of Autohelm and **not** compatible with NMEA or CAN. Unfortunately Raymarine keeps the technical details of SeaTalk secret. To assist users who want to develop hard- or software to connect their devices to the SeaTalk bus these pages uncover some of the mysteries. Part 3 adds hints how to interface SeaTalk with a PC. The information is unsupported by Raymarine and was found by watching the bits travelling on the bus. Therefore the description is incomplete inaccurate and may even be wrong. [Corrections and contributions](#) are welcome.

Content

The technical description of the SeaTalk protocol is divided into three parts:

1. [Part 1: How SeaTalk works](#)
 - a. [Hardware-Interface](#) describes the function of the three SeaTalk wires
 - b. [Serial Data Transmission](#) describes the parameters of the asynchron serial port
 - c. [Composition of Messages](#) describes the structure of datagrams
 - d. [Collision Management](#) describes the arbitration between simultaneous talkers
 - e. [Data Coding](#) describes common rules for coding numerical values
2. [Part 2: Recognized Datagrams](#) describes the SeaTalk messages and their meaning
3. [Part 3: Processing SeaTalk Data with a PC](#)
 - a. [Circuit example for an unidirectional SeaTalk => PC interface](#)
 - b. [Circuit example for a bidirectional SeaTalk <=> PC interface](#)
 - c. [Simple SeaTalk monitoring utility for download](#)
 - d. [SeaTrack: VisualBasic software for trip documentation](#)
 - e. [SeaSigma: A small SeaTalk command generator for download](#)

Revision History:

Rev 3.22: [May 2014] Command 53 corrected thx John Rind and Mindert Sprang
Rev 3.21: [March 2011] Time coding in command 54 clarified thx Tim Thornton
Rev 3.20: [January 2011] Some observations with Raystar 120 GPS included thx Tim Thornton
Rev 3.19: [August 2010] Command A2 revised thx Frank Wallenwein
Rev 3.18: [March 2009] Several commands edited and new commands 05 and 68 added thx Frank Wallenwein
Rev 3.17: [February 2009] Command A4 added thx Tord Lindner
Rev 3.16: [October 2008] Commands 65, 66, A8 and AB added thx Ray Holland

Rev 3.15: [June 2006] Command 61 added thx Ian Molesworth
Rev 3.14: [January 2006] Minor changes to commands 26, 01 and 6C thx Ian Molesworth
Rev 3.13: [December 2005] Additional bits found in command 26 by Pim Snoeks
Rev 3.12: [September 2005] Additional bits found in command 84 by Pim Snoeks

Acknowledgement

Many thanks to

Knut Wiren, Finland

[Mikael Wahlgren](#), Sweden (developed a PIC-based SeaTalk remote control)

Reiner Patommel, Danmark

Arnold de Maa, Holland

[Wouter van Ooijen](#), Netherlands (developed a PIC-based SeaTalk protocol converter)

[Jürgen Saniter](#), Germany (developed a SX-28 based SeaTalk remote control)

Harald Sammer, Scotland

Ales Janhar, Slovenija (developed the SeaSigma utility)

[Jon Fick](#), USA (developed a PIC-based SeaTalk remote control)

[Frank Wallenwein](#), Germany ([NMEA <=> SeaTalk Bridge and several boat electronics projects](#))

Dave Martin, Great Britain

Horacio Martinez del Pezzo, Argentina (developed an intelligent SeaTalk / NMEA multiplexer)

[Pit Förster and Jochen Buttkeireit](#), Germany (supplier of third party SeaTalk equipment for instance [Brookhouse interfaces](#))

[Louis Zammit Mangion](#), Malta (developed a PIC-based SeaTalk remote control)

[Meindert Sprang](#), Netherlands (develops and manufactures NMEA/SeaTalk/Bluetooth/RS232-multiplexers)

Dennis Hambleton, Australia

[Fernando MAS CADIZ](#), Spain

Ray Holland, Australia (developed a [WakeUp Marine Alarm](#) box)

Tord Lindner, Sweden and

Tim Thornton, United Kingdom ([TeamSurv](#) project for navigational data logging and [Smartcom Software Ltd.](#))

who contributed valuable information for this page.

[Return to Top of Page](#) [Part 1](#) [Part 2](#) [Part 3](#)

SeaTalk Technical Reference Part 1: How SeaTalk works

Hardware-Interface

SeaTalk uses three wires, connected in parallel to all devices on the bus:

1. +12V Supply, red
2. GND Supply, grey
3. Data Serial Data, yellow: +12V=Idle/Mark=1, 0V=Space/Data=0, 4800 Baud, pullup circuit in each device, talker pulls down to 0V (wired OR). For [connection to a RS232 receiver](#) voltage levels must be inverted.

Serial Data Transmission

11 bits are transmitted for each character:

- 1 Start bit (0V)
- 8 Data Bits (least significant bit transmitted first)
- 1 Command bit, set on the first character of each datagram. Reflected in the parity bit of most UARTs. Not compatible with NMEA0183 but well suited for the multiprocessor communications mode of 8051-family microcontrollers (bit SM2 in SCON set).
- 1 Stop bit (+12V)

Composition of Messages

Each datagram contains between 3 and 18 characters:

1. Type of command (the only byte with the command-bit set)
2. Attribute Character, specifying the total length of the datagram in the least significant nibble:

Most significant 4 bits: 0 or part of a data value

Least significant 4 bits: Number of additional data bytes = n =>

Total length of datagram = 3 + n characters

3. First, mandatory data byte
4. - 18. optional, additional data bytes

No datagrams or devices carry addresses. This eliminates the need for an initialization or arbitration phase on the bus. Events (such as a keystroke) are published as soon as they occur. Measured data is repeatedly transferred, typically about once per second. So the current values are always available to all devices on the bus and there is no need (and with the exception of command A4 no way) to request a particular information.

Collision Management

There is no master on the bus. Every device has equal rights and is allowed to talk as soon as it recognizes the bus to be idle (+12V for at least 10/4800 seconds). Low priority messages use a longer or randomly selected idle-bus-waiting-time. This allows messages from other devices with a higher priority to be transmitted first. The different waiting times of all devices make data collisions (two or more devices start talking at exactly the same moment) very rare. Since each device also listens to its own transmission it will recognize when its message is garbled by a second talker. In this case it abandons the remaining characters of the datagram. It waits for the bus to become free again and then retransmits the whole message. For listeners this means that messages which are shorter than expected are invalid and have to be cancelled totally.

Data Coding

Some characters are repeated with all bits inverted for noise or transmission error detection. Example: 0xA2 is followed by 0x5D. The sum of both bytes must always be 0xFF. The listing below shows repeated bytes in small letters (example: ZZ zz).

Numerical values are transmitted binary coded and with least significant data first. Example: 0x13 0x57 means $0x5713 = 22291$

Some values are put together by certain bits of a byte or nibble. The meaningful bits can be isolated by a bitwise AND operation (&). Example: (U & 0x3) filters the least significant two bits of U.

The "distance to destination" value (ZZZ in command 0x85) uses a scaling factor of 1/10 or 1/100 nm depending on the shift indicator bit (LSBit of Y).

[Return to Top of Page](#) [Part 1](#) [Part 2](#) [Part 3](#)

SeaTalk Technical Reference Part 2:

Recognized Datagrams (in hexadecimal notation):

Com Att Dat Dat...

00 02 YZ XX XX Depth below transducer: XXXX/10 feet
Flags in Y: Y&8 = 8: Anchor Alarm is active
Y&4 = 4: Metric display units or
Fathom display units if followed

by command 65

Y&2 = 2: Used, unknown meaning
Flags in Z: Z&4 = 4: Transducer defective
Z&2 = 2: Deep Alarm is active
Z&1 = 1: Shallow Depth Alarm is active
Corresponding NMEA sentences: DPT, DBT

01 05 XX XX XX XX XX XX Equipment ID, sent at power on, reported
examples:

01 05 00 00 00 60 01 00 Course Computer 400G
01 05 04 BA 20 28 01 00 ST60 Tridata
01 05 70 99 10 28 01 00 ST60 Log
01 05 F3 18 00 26 0F 06 ST80 Masterview
01 05 FA 03 00 30 07 03 ST80 Maxi Display
01 05 FF FF FF D0 00 00 Smart Controller Remote Control Handset

05 03 0X YY ZZ PP Engine RPM and PITCH:
X = 0: RPM & PITCH
X = 1: RPM & PITCH starboard
X = 2: PRM & PITCH port
YY*256+ZZ = RPM Value (signed value, example:
YYZZ=0x0110=272 RPM, YYZZ=0xfef0= -272 RPM)
PP = % Pitch (signed value -128%...+127%, example
0x03=3%, 0xFD= -3%)

10 01 XX YY Apparent Wind Angle: XXYY/2 degrees right of bow
Used for autopilots Vane Mode (WindTrim)
Corresponding NMEA sentence: MWV

11 01 XX 0Y Apparent Wind Speed: (XX & 0x7F) + Y/10 Knots
Units flag: XX&0x80=0 => Display value in Knots
XX&0x80=0x80 => Display value in Meter/Second
Corresponding NMEA sentence: MWV

20 01 XX XX Speed through water: XXXX/10 Knots
Corresponding NMEA sentence: VHW

21 02 XX XX 0X Trip Mileage: XXXXX/100 nautical miles

22 02 XX XX 00 Total Mileage: XXXX/10 nautical miles

23 Z1 XX YY Water temperature (ST50): XX deg Celsius, YY deg Fahrenheit
Flag Z&4: Sensor defective or not connected (Z=4)
Corresponding NMEA sentence: MTW

24 02 00 00 XX Display units for Mileage & Speed
XX: 00=nm/knots, 06=sm/mph, 86=km/kmh

25 Z4 XX YY UU VV AW Total & Trip Log
total= (XX+YY*256+Z* 4096)/ 10 [max=104857.5] nautical
miles
trip = (UU+VV*256+W*65536)/100 [max=10485.75] nautical
miles

26 04 XX XX YY YY DE Speed through water:
XXXX/100 Knots, sensor 1, current speed, valid if D&4=4
YYYY/100 Knots, average speed (trip/time) if D&8=0
or data from sensor 2 if D&8=8
E&1=1: Average speed calculation stopped
E&2=2: Display value in MPH
Corresponding NMEA sentence: VHW

27 01 XX XX Water temperature: (XXXX-100)/10 deg Celsius
Corresponding NMEA sentence: MTW

30 00 0X Set lamp Intensity; X=0: L0, X=4: L1, X=8: L2, X=C: L3
(only sent once when setting the lamp intensity)

36 00 01 Cancel MOB (Man Over Board) condition

38 X1 YY yy Codelock data

50 Z2 XX YY YY LAT position: XX degrees, (YYYY & 0x7FFF)/100 minutes
MSB of Y = YYYY & 0x8000 = South if set, North if
cleared
Z= 0xA or 0x0 (reported for Raystar 120 GPS), meaning
unknown
Stable filtered position, for raw data use command 58
Corresponding NMEA sentences: RMC, GAA, GLL

51 Z2 XX YY YY LON position: XX degrees, (YYYY & 0x7FFF)/100 minutes
MSB of Y = YYYY & 0x8000 = East if set, West if cleared
Z= 0xA or 0x0 (reported for Raystar 120 GPS), meaning
unknown
Stable filtered position, for raw data use command 58
Corresponding NMEA sentences: RMC, GAA, GLL

52 01 XX XX Speed over Ground: XXXX/10 Knots
Corresponding NMEA sentences: RMC, VTG

53 U0 VW Magnetic Course in degrees:
The two lower bits of U * 90 +
the six lower bits of VW * 2 +
the two higher bits of U / 2 =
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC) / 8$
The Magnetic Course may be offset by the Compass Variation
(see datagram 99) to get the Course Over Ground (COG).
Corresponding NMEA sentences: RMC, VTG

54 T1 RS HH GMT-time: HH hours,
6 MSBits of RST = minutes = $(RS \& 0xFC) / 4$
6 LSBits of RST = seconds = $ST \& 0x3F$
Corresponding NMEA sentences: RMC, GAA, BWR, BWC

55 X1 YY yy TRACK keystroke on GPS unit
keycodes identical with autopilot ([command 86](#))

56 M1 DD YY Date: YY year, M month, DD day in month
Corresponding NMEA sentence: RMC

57 S0 DD Sat Info: S number of sats, DD horiz. dillution of position,
if S=1 -> DD=0x94
Corresponding NMEA sentences: GGA, GSA

58 Z5 LA XX YY LO QQ RR LAT/LON
LA Degrees LAT, LO Degrees LON
minutes LAT = $(XX*256+YY) / 1000$
minutes LON = $(QQ*256+RR) / 1000$
Z&1: South (Z&1 = 0: North)
Z&2: East (Z&2 = 0: West)
Raw unfiltered position, for filtered data use commands
50&51
Corresponding NMEA sentences: RMC, GAA, GLL

59 22 SS MM XH Set Count Down Timer
MM=Minutes (00..3B) (00 .. 63 Min), MSB:0 Count up
start flag
SS=Seconds (00..3B) (00 .. 59 Sec)
H=Hours (0..9) (00 .. 09 Hours)
X= Counter Mode: 0 Count up and start if MSB of MM set
4 Count down
8 Count down and start
(Example 59 22 3B 3B 49 -> Set Countdown Timer to 9.59:59
)
59 22 0A 00 80 Sent by ST60 in countdown mode when counted down to 10
Seconds.

61 03 03 00 00 00 Issued by E-80 multifunction display at initialization

65 00 02 Select Fathom (feet/3.33) display units for depth display
(see command 00)

66 00 XY Wind alarm as indicated by flags in XY:
X&8 = 8: Apparent Wind angle low
X&4 = 4: Apparent Wind angle high

X&2 = 2: Apparent Wind speed low
X&1 = 1: Apparent Wind speed high
Y&8 = 8: True Wind angle low
Y&4 = 4: True Wind angle high
Y&2 = 2: True Wind speed low
Y&1 = 1: True Wind speed high (causes Wind-High-Alarm on
ST40 Wind Instrument)
XY =00: End of wind alarm (only sent once)

68 X1 01 00 Alarm acknowledgment keystroke (from ST80 Masterview)
68 X1 03 00 Alarm acknowledgment keystroke (from ST80 Masterview)
68 41 15 00 Alarm acknowledgment keystroke (from ST40 Wind Instrument)
X: 1=Shallow Shallow Water Alarm, 2=Deep Water Alarm,
3=Anchor Alarm
4=True Wind High Alarm, 5=True Wind Low Alarm, 6=True
Wind Angle high
7=True Wind Angle low, 8=Apparent Wind high Alarm,
9=Apparent Wind low Alarm
A=Apparent Wind Angle high, B=Apparent Wind Angle low

6C 05 XX XX XX XX XX XX Second equipment-ID datagram (follows 01...),
reported examples:
6C 05 04 BA 20 28 2D 2D ST60 Tridata
6C 05 05 70 99 10 28 2D ST60 Log
6C 05 F3 18 00 26 2D 2D ST80 Masterview

6E 07 00 00 00 00 00 00 00 00 MOB (Man Over Board), (ST80), preceded
by a Waypoint 999 command: 82 A5 40 BF 92 6D 24 DB

70 10 XY Keystroke on Raymarine A25006 ST60 Maxiview Remote Control
X=0 => Single keypress; X=2 => Two keys pressed;
X=4 => Single key: Press,hold&release; X=6 => Two keys:
Press,hold&release
Y=0 => Key 1 "Depth"; Y=1 => Key 2 "Speed" or Keys 1+2;
Y=2 => Key 3 "HDG" or Keys 2+4; Y=3 => Key 4 "Wind" or
Keys 1+3;
Y=4 => Keys 3+4 "Nav"

80 00 0X Set Lamp Intensity: X=0 off, X=4: 1, X=8: 2, X=C: 3

81 01 00 00 Sent by course computer during setup when going past USER
CAL.
81 00 00 Sent by course computer immediately after above.

82 05 XX xx YY yy ZZ zz Target waypoint name
XX+xx = YY+yy = ZZ+zz = FF (allows error detection)
Takes the last 4 chars of name, assumes upper case only
Char= ASCII-Char - 0x30
XX&0x3F: char1
(YY&0xF)*4+(XX&0xC0)/64: char2
(ZZ&0x3)*16+(YY&0xF0)/16: char3
(ZZ&0xFC)/4: char4
Corresponding NMEA sentences: RMB, APB, BWR, BWC

83 07 XX 00 00 00 00 00 80 00 00 Sent by course computer.
 XX = 0 after clearing a failure condition, also sent once
 after power-up.
 XX = 1 failure, auto release error. Repeated once per
 second.
 XX = 8 failure, drive stopped.

84 U6 VW XY OZ OM RR SS TT Compass heading Autopilot course and
 Rudder position (see also command 9C)
 Compass heading in degrees:
 The two lower bits of U * 90 +
 the six lower bits of VW * 2 +
 number of bits set in the two higher bits of U =
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC ? (U \& 0xC ==$
 $0xC ? 2 : 1) : 0)$
 Turning direction:
 Most significant bit of U = 1: Increasing heading, Ship
 turns right
 Most significant bit of U = 0: Decreasing heading, Ship
 turns left
 Autopilot course in degrees:
 The two higher bits of V * 90 + XY / 2
 Z & 0x2 = 0 : Autopilot in Standby-Mode
 Z & 0x2 = 2 : Autopilot in Auto-Mode
 Z & 0x4 = 4 : Autopilot in Vane Mode (WindTrim), requires
 regular "10" datagrams
 Z & 0x8 = 8 : Autopilot in Track Mode
 M: Alarms + audible beeps
 M & 0x04 = 4 : Off course
 M & 0x08 = 8 : Wind Shift
 Rudder position: RR degrees (positive values steer right,
 negative values steer left. Example: 0xFE = 2° left)
 SS & 0x01 : when set, turns off heading display on 600R
 control.
 SS & 0x02 : always on with 400G
 SS & 0x08 : displays "NO DATA" on 600R
 SS & 0x10 : displays "LARGE XTE" on 600R
 SS & 0x80 : Displays "Auto Rel" on 600R
 TT : Always 0x08 on 400G computer, always 0x05 on 150(G)
 computer

85 X6 XX VU ZW ZZ YF 00 yf Navigation to waypoint information
 Cross Track Error: XXX/100 nautical miles
 Example: X-track error 2.61nm => 261 dec => 0x105 =>
 X6XX=5_10
 Bearing to destination: $(U \& 0x3) * 90^\circ + WV / 2^\circ$
 Example: GPS course $230^\circ = 180 + 50 = 2 * 90 + 0x64 / 2$ => VUZW=42_6
 U&8: U&8 = 8 -> Bearing is true, U&8 = 0 -> Bearing is
 magnetic
 Distance to destination: Distance 0-9.99nm: ZZZ/100nm, Y &
 1 = 1
 Distance >=10.0nm: ZZZ/10 nm, Y &
 1 = 0
 Direction to steer: if Y & 4 = 4 Steer right to correct
 error
 if Y & 4 = 0 Steer left to correct

error

Example: Distance = 5.13nm, steer left: $5.13 \times 100 = 513 = 0x201 \Rightarrow ZW ZZ YF=1_ 20 1_$

Distance = 51.3nm, steer left: $51.3 \times 10 = 513 = 0x201 \Rightarrow ZW ZZ YF=1_ 20 0_$

Track control mode:

F= 0x1: Display x-track error and Autopilot course

F= 0x3: Enter Track Control Mode, i.e. lock on to GPS.
Display x-track error, autopilot course and

bearing

to destination

F= 0x5: Display x-track error, distance to waypoint,
autopilot course and bearing to destination

normal--> F= 0x7: Enter Track Control Mode, i.e. lock on to GPS.
Display x-track error, distance to waypoint,
autopilot course and bearing to destination

F= 0xF: As 0x7 but with x-track error alarm

F= 2, 4, 6, 8 ... causes data errors

In case of a waypoint change, sentence 85, indicating the
new bearing and distance,

should be transmitted prior to sentence 82 (which
indicates the waypoint change).

Corresponding NMEA sentences: RMB, APB, BWR, BWC, XTE

86 X1 YY yy Keystroke

X=1: Sent by Z101 remote control to increment/decrement
course of autopilot

11	05	FA	-1	
11	06	F9	-10	
11	07	F8	+1	
11	08	F7	+10	
11	20	DF	+1 & -1	
11	21	DE	-1 & -10	
11	22	DD	+1 & +10	
11	28	D7	+10 & -10	
11	45	BA	-1	pressed longer than 1 second
11	46	B9	-10	pressed longer than 1 second
11	47	B8	+1	pressed longer than 1 second
11	48	B7	+10	pressed longer than 1 second
11	60	DF	+1 & -1	pressed longer than 1 second
11	61	9E	-1 & -10	pressed longer than 1 second
11	62	9D	+1 & +10	pressed longer than 1 second
11	64	9B	+10 & -10	pressed longer than 1 second (why not 11 68 97

?)

Sent by autopilot (X=0: ST 1000+, X=2: ST4000+ or ST600R)

X1	01	FE	Auto
X1	02	FD	Standby
X1	03	FC	Track
X1	04	FB	disp (in display mode or page in auto chapter = advance)
X1	05	FA	-1 (in auto mode)
X1	06	F9	-10 (in auto mode)
X1	07	F8	+1 (in auto mode)
X1	08	F7	+10 (in auto mode)
X1	09	F6	-1 (in resp or rudder gain mode)
X1	0A	F5	+1 (in resp or rudder gain mode)

```

X1 21 DE    -1 & -10 (port tack, doesn't work on ST600R?)
X1 22 DD    +1 & +10 (stb tack)
X1 23 DC    Standby & Auto (wind mode)
X1 28 D7    +10 & -10 (in auto mode)
X1 2E D1    +1 & -1 (Response Display)
X1 41 BE    Auto pressed longer
X1 42 BD    Standby pressed longer
X1 43 BC    Track pressed longer
X1 44 BB    Disp pressed longer
X1 45 BA    -1 pressed longer (in auto mode)
X1 46 B9    -10 pressed longer (in auto mode)
X1 47 B8    +1 pressed longer (in auto mode)
X1 48 B7    +10 pressed longer (in auto mode)
X1 63 9C    Standby & Auto pressed longer (previous wind angle)
X1 68 97    +10 & -10 pressed longer (in auto mode)
X1 6E 91    +1 & -1 pressed longer (Rudder Gain Display)
X1 80 7F    -1 pressed (repeated 1x per second)
X1 81 7E    +1 pressed (repeated 1x per second)
X1 82 7D    -10 pressed (repeated 1x per second)
X1 83 7C    +10 pressed (repeated 1x per second)
X1 84 7B    +1, -1, +10 or -10 released

87 00 0X    Set Response level
              X=1 Response level 1: Automatic Deadband
              X=2 Response level 2: Minimum Deadband

88 03 WW XX YY ZZ Autopilot Parameter: Sent by AP every
                    second while in parameter setting mode.
                    (User or Dealer Calibration Mode)
                    WW Parameter Number
                    XX Current Setting
                    YY Max Parameter Value
                    ZZ Min Parameter Value
                    Known Paramters: Parameter (min-max)
[default]    Number
              rudder gain (1-9)
[2]          1
              counter rudder (1-9)
[2]          2
              rudder limit (10-40)
[30]         3
              turn rate limit (1-30)
[off]        4
              speed (4-60)
[8]          5
              off course limit (15-40)
[20]         6
              auto trim (0-4)
[1]          7
              power steer [Joy Stick] ON/OFF (not on new
400G)        9
              drive type (3,4,5)
[3]          A
              rudder damping (1-9)
[2]          B
              variation: (full degrees) (-30 to +30)

```

```

[0]          C
          auto adapt: 0=Off,1=North,2=South
[1]          D
          auto adapt latitude (0-80)
[0]          E
          auto release (only for stern drive)
ON/OFF      F
          rudder alignment (-7 to +7)
[0]          10
          Wind Trim (Wind Response) (1-9) [5] (only for
sail)      11
          Response (1-9)
[5]          12
          Boat type:1=displ,2=semi-
displ,3=plan,4=stern,5=work,6=sail 13
          Cal Lock: 0=OFF, 1=ON
[0]          15
          Auto Tack Angle (40-125) [100] (only for
sail)      1d

89 U2 VW XY 2Z Compass heading sent by ST40 compass instrument
          (it is read as a compass heading by the ST1000(+) or
ST2000(+) autopilot)
          Compass heading in degrees:
          The two lower bits of U * 90 +
          the six lower bits of VW * 2 +
          the two higher bits of U / 2 =
          (U & 0x3) * 90 + (VW & 0x3F) * 2 + (U & 0xC) / 2
          Locked steer reference (only send by the ST40 compass):
          The two higher bits of V * 90 + XY / 2
          Z & 0x2 = 0 : St40 in Standby mode
          Z & 0x2 = 2 : St40 in Locked steer mode
          Corresponding NMEA sentences: HDM, HDG, HDT, VHW

90 00 XX      Device Identification
          XX=02 sent by ST600R ~every 2 secs
          XX=05 sent by type 150, 150G and 400G course computer
          XX=A3 sent by NMEA <-> SeaTalk bridge ~every 10 secs

91 00 0X      Set Rudder gain to X

92 02 XX YY 00 Set Autopilot Parameter: Sent by the remote head
          (e.g. ST600R) to set a particular parameter.
          XX Parameter Number (see 88)
          YY Value to set to.

93 00 00      Enter AP-Setup: Sent by course computer before
          finally entering the dealer setup. It is repeated
          once per second, and times out after ten seconds.
          While this is being sent, command 86 X1 68 97 is
          needed for final entry into Setup. (600R generates
          this when -1 & +1 are pressed simultaneously in this
          mode).

```

95 U6 VW XY OZ 00 RR 00 OT Replaces command 84 while autopilot is in value setting mode
e.g. lamp intensity or response level

99 00 XX Compass variation sent by ST40 compass instrument or ST1000, ST2000, ST4000+, E-80 every 10 seconds but only if the variation is set on the instrument
Positive XX values: Variation West, Negative XX values: Variation East
Examples (XX => variation): 00 => 0, 01 => -1 west, 02 => -2 west ...
FF => +1 east, FE => +2 east
...
Corresponding NMEA sentences: RMC, HDG

9A 09 L11 L12 L13 L14 L21 L22 L23 00 00 00 Version String:
L11 means line 1 char 1. There are two lines, line 1 can have 4 characters and line two can have 3 characters. Char: "A"= 0x00, "B"= 0x01,.....
Char: "0"= 0x25, "1"= 0x26,
Some special characters are mapped to the range between alphas and numeric chars. It seems modulo masked at 0x36, and wraps around from there.

9C U1 VW RR Compass heading and Rudder position (see also command 84)
Compass heading in degrees:
The two lower bits of U * 90 +
the six lower bits of VW * 2 +
number of bits set in the two higher bits of U =
(U & 0x3) * 90 + (VW & 0x3F) * 2 + (U & 0xC ? (U & 0xC == 0xC ? 2 : 1) : 0)
Turning direction:
Most significant bit of U = 1: Increasing heading, Ship turns right
Most significant bit of U = 0: Decreasing heading, Ship turns left
Rudder position: RR degrees (positive values steer right,
negative values steer left. Example: 0xFE = 2° left)
The rudder angle bar on the ST600R uses this record

9E FC 49 49 03 XX AA BB YY OO PP GG HH II JJ Waypoint definition
XX: Degrees LAT, YY: Degrees LON
min&sec LAT= AA+(BB&0x1F)*256, BB&0x80 = 0: North, BB&0x80 = 0x80: South
min&sec LON= OO+(PP&0x1F)*256, PP&0x80 = 0: West, PP&0x80 = 0x80: East
GG HH II JJ: Last four characters of waypoint name

A1 XD 49 49 GG HH II JJ C1 C2 C3 C4 C5 C6 C7 C8 Destination Waypoint Info
GG HH II JJ: Last four characters of waypoint name
C1...C8: Up to 8 characters of WP name, unused are 0
Longer names (> 8 chars) create an additional record:
X=0: single record (short name)
X=1: 1st record, more follows

X=3: last record
Corresponding NMEA sentences: RMB, APB, BWR, BWC

A2 X4 00 WW XX YY ZZ Arrival Info
X&0x2=Arrival perpendicular passed, X&0x4=Arrival circle
entered

WW,XX,YY,ZZ = Ascii char's of waypoint id. (0..9,A..Z)
Takes the last 4 chars of name, assumes

upper case only

Corresponding NMEA sentences: APB, AAM

A4 02 00 00 00 Broadcast query to identify all devices on the bus, issued
e.g. by C70 plotter

A4 06 00 00 00 00 00 Termination of request for device identification,
sent e.g. by C70 plotter

A4 12 II VV WW Device answers identification request
II: Unit ID (01=Depth, 02=Speed, 03=Multi, 04=Tridata,
05=Tridata repeater,
06=Wind, 07=WGM, 08=Navdata GPS,
09=Maxview, 0A=Steering compas,
0B=Wind Trim, 0C=Speed trim, 0D=Seataalk
GPS, 0E=Seataalk radar ST50,
0F=Rudder angle indicator, 10=ST30 wind,
11=ST30 bidata, 12=ST30 speed,
13=ST30 depth, 14=LCD navcenter, 15=Apelco
LCD chartplotter,
16=Analog speedtrim, 17=Analog depth,
18=ST30 compas,
19=ST50 NMEA bridge, A8=ST80 Masterview)
VV: Main Software Version
WW: Minor Software Version

A5 GPS and DGPS Info
A5 57 QQ HH ?? AA GG ZZ YY DD GPS and DGPS Fix Info
Signal Quality= QQ&0xF, QQ&0x10: Signal Quality available
flag

HDOP= HH&0x7C, HH&0x80: HDOP available flag
Antenna Height= AA
Number of Sats= (QQ&0xE0)/16+(HH&0x1), HH&0x2: NumSats
available flag
GeoSeperation= GG*16 (-2048....+2047 meters)
Differential age=(ZZ&0xE0)/2+(YY&0xF), YY&0x10: Diff. age
available flag

Differential Station ID=(YY&0xC0)*4+DD, YY&0x20:
Diff.St.ID available flag
Corresponding NMEA sentences: GGA, RMC, GSV, GLL, GGA
A5 61 04 E2 , A5 8D ..., A5 98 ..., A5 B5 ..., A5 0C... Unknown
meaning

A5 74 ID ID ID ID ID GPS Info: ID numbers of satellites
A5 XD NN AA EE SS MM BB FF GG OO CC DD XX YY ZZ GPS Info: Sat Position
and Signal

Data of up to three sattelites [1,2,3] per datagram
Satellite number: [1] NN&0xFE, [2] (MM&0x70)/2+(BB&0x7),
[3] CC&0x3F

Satellite azimuth:[1] AA*2+(EE&0x1), [2]
(BB&0xF8)*2+(FF&0xF), [3] (CC&0xC0)*2+DD&0x7F

Satellite elevation: [1] (EE&0xFE)/2, [2]
(FF&0xF0)/2+GG&0x7, [3] XX&0x7F
Satellite signal: [1] (SS&0xFE)/2, [2]
(GG&0x80)/2+OO&0x3F, [3] (YY&0xFC)/2+ZZ&0x1

It seems that there will be 4 sat info datagrams generated, the first with X=0 carries the position and signal data of the 1st 3 satellites. The second also with X=0, but NN&0x1 set and a length of 0x0C carries the data of the next 2 satellites and then the ID numbers of the 1st 4 sats. A datagram like the 1st one, but with X=2 carries data of 3 more sats [6,7,8]. It was not possible to get more than 8 sats mapped to SeaTalk. Finally a datagram with X=7 carries the next 5 ID numbers.

Corresponding NMEA sentences: GSV, GSA


A7 09 86 000000000000000079 Unknown meaning, sent by Raystar 120 GPS
A8 53 80 00 00 D3 Alarm ON for Guard #1 or #2
A8 43 80 00 00 C3 Alarm OFF for Guard #1 or #2
AB 53 80 00 00 D3 Alarm ON for Guard #1 or #2
AB 43 80 00 00 C3 Alarm OFF for Guard #1 or #2

[Return to Top of Page](#) [Part 1](#) [Part 2](#) [Part 3](#)

SeaTalk Technical Reference Part 3: Processing SeaTalk Data with a PC


Unidirectional SeaTalk => RS232 Interface

This simple unidirectional interface circuit inverts the SeaTalk signal to make it readable by the PC serial port:



Bidirectional SeaTalk <=> RS232 Interface

For bidirectional communication the circuit has to be extended by a second transistor:



A PC-board may be obtained from [Frank Wallenwein](#).

SeaTalk Monitor

The following piece of C-code gives an example of how to collect and process SeaTalk data. It monitors the SeaTalk bus and echoes the SeaTalk datagrams in hexadecimal notation to the screen.

```
#include <stdio.h>

/* Set Address of Serial Port: COM1=0x3F8, COM2=0x2F8 */
#define PORT 0x3F8

unsigned int collision_ctr,overrun_ctr;
char buffer[256],in_ptr,out_ptr,limit_ptr;
char line_status_reg,receiver_buf,byte_ctr;
char hex[]="0123456789ABCDEF";

main() {
    puts("SeaTalk Monitor Rev. 1.01      (c)2000 by Thomas Knauf\r\n");

    /* Serial Port Initialization */
    _outb( 0, PORT+1); /*IER Disable Interrupts */
    _outb( 1, PORT+2); /*FCR Enable Fifo */
    _outb(0x80, PORT+3); /*LCR Enable access to Divisor Latch */
    _outb( 24, PORT ); /*DLL Set Baud Rate to 4800 LSB*/
    _outb( 0, PORT+1); /*DLM Baud Rate Divisor MSB */
    _outb(0x3B, PORT+3); /*LCR Stick Parity to 0, Enable Parity, 1 Stop bit, 8
bits/char */
    _outb(0x0F, PORT+4); /*MCR Disable LOOP Mode */
    _outb( 0, PORT+5); /*LSR Clear Error flags */

    while(1) { /* Continous data processing loop */
        if((line_status_reg= _inb(PORT+5)) & 1) { /* LSR New SeaTalk Data received
? */
            receiver_buf=_inb(PORT); /* RBR Read SeaTalk Data Byte */
            if(line_status_reg & 2) overrun_ctr++; /* PC too slow, should not happen
*/
            if(line_status_reg & 4) { /* Parity bit set => Command Byte */
                if(byte_ctr) { /* More characters expected => Collision */
                    in_ptr=limit_ptr; /* Discard last datagram, restart from
beginning */
                    collision_ctr++; /* Count collision events */
                }
                buffer[in_ptr++]='\r'; /* Put new command on new line */
                buffer[in_ptr++]='\n';
                byte_ctr=255; /* Undefined datagram length, wait for next
character */
            } else
                if(byte_ctr==254) /* Attribute byte ? */
                    byte_ctr=(receiver_buf & 0xF) + 2; /* Read expected datagram length
*/
            if(byte_ctr) { /* Process valid data bytes, should always be
true */
                buffer[in_ptr++]=hex[receiver_buf >> 4]; /* Convert Data to hex */
            }
        }
    }
}
```

```

        buffer[in_ptr++]=hex[receiver_buf & 0xF];
        buffer[in_ptr++]=' ';          /* Seperate by space */
        if(! --byte_ctr) limit_ptr=in_ptr;      /* Complete datagram ready
for output */
    }
    } else
        if(out_ptr != limit_ptr)          /* Characters waiting for Output ? */
            putchar(buffer[out_ptr++],stdout); /* Copy single character from buffer
to screen */
        else if(scr_csts()) break;        /* Query keyboard, terminate if any
key hit */
    }
    printf("\r\nSeataalk Collisions : %5u",collision_ctr);
    printf("\r\nUART Overrun Errors: %5u",overrun_ctr);
}

```

Compiled EXE-Files can be downloaded here as [SEAMON1.EXE](#) (using COM1:) or [SEAMON2.EXE](#) (using COM2:). They run in any MS-DOS environment. Redirecting the output logs data to a file (example: SEAMON1 > LOGFILE). Pressing any key terminates the program.

SeaTrack: Route documentation software

The [SeaTrack](#) software developed by Philip Beekman for reading editing combining displaying and saving trip routes is able to handle SeaTalk data directly. The author also describes how he solved the problem to handle the [parity/command-bit interpetation within VisualBasic](#).

SeaSigma: A simple SeaTalk command generator

The file [SeaSigma.zip](#) contains a MS-Windows program which allows to generate SeaTalk commands and to send them via COM1: or COM2: to the SeaTalk bus. Since SeaSigma is a contribution of [Ales Janhar](#) I cannot give support or take any responsibility for this software.

[Return to Top of Page](#) [Part 1](#) [Part 2](#) [Part 3](#)